

# P0 Rotating CCT control panel

Model No.: P0


#### **Product Feature**


- · Stepless dimming, color temperature and brightness adjustable
- 4096 levels of smooth dim., min. brightness can reach 0.1%
- Can pair with 12 remote controllers (control distance 30m)
- Auto-forwarding: The controller auto-forwards the signal directly, making the remote control distance infinite
- Supports Do Not Disturb mode setting, suitable for areas with frequent power outages to save electricity
- Support "Tuya Smart" APP control (2.4G gateway required)
- Support Alexa, Google Assistant, Yandex Alice, Tmall Genie,
   Xiaodu, Xiaoai (2.4G gateway required)




# **Product Parameter**

Rotating CCT control panel	Dimming Level:	-10~40°C
P0	Dimming Range:	0.1~100%
DC12V~48V	Dimming Curve:	Logarithm
Max 12A	EMC Standards (EMC):	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-3 V2.3.1
144~576W		
Constant voltage output	Safety Standard (LVD):	EN 61347-1: 2015+A1:2021 EN 61347-2-11: 2001+A1: 2019
2.4GHz		
30m	Radio equipment (RED) :	ETSI EN 300 400 V2.2.1
IP20	Certification:	CE\EMC\LVD\RED
-10~40°C	Warranty:	5 Year
	P0 DC12V-48V Max 12A 144~576W Constant voltage output 2.4GHz 30m	P0 Dimming Range: DC12V-48V Dimming Curve: Max 12A 144-576W Constant voltage output 2.4GHz 30m Radio equipment (RED): IP20 Certification:





## Indication




Rotate Right: Brighten/Cool Light

Long press: switch dimming mode

Dim CCT: Long press until indicator changed to yellow

## Link/Unlink


#### Link



turn off light 10 seconds and turn on again



short press "ON" 3 times within 3 seconds




link is done once light flashes 3 times slowlyyy



Link is failed if light doesn't flash, please repeat above steps (Attention: can not link again if remote already finished linking)


#### Unlink:



turn off light 10 seconds and turn on again



short press "ON" 5 times within 3




10 times quickly




Unlink is faild if light doesn't flash, please repeat above steps (Attention: no need to unlink if the light never be linked)

# Compatible Remote (purchase separately)



### **Connection Diagram**



#### Attention

- 1.Please ensure that voltage, N and L are correct connection, it will damage the light with wrong wiring
- 2.Please turn off mains before wiring cable and ensure that connection don't have any problem like short circuit
- 3.Don't disassemble it if you are not expert
- 4.Don't use it near magnetic or metal area, it will affect signal and reduce distance.

